





# Xbox One Optical Drive Assembly Replacement

Prereq only, used before fan and motherboard guides

Written By: Andrew Optimus Goldberg



## Step 1 — Optical Drive Assembly



- Disconnect the optical drive power and SATA data cables from the motherboard.

## Step 2



- Remove the optical drive assembly from the Xbox.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 03:23:03 PM.